




ROXI

INTIMATE DUAL VIBE INSTRUCTION MANUAL

nobü®
the art of pleasure

01

GETTING STARTED:

- Be sure to fully charge your toy before first use.
- Press and hold  to turn the device on.
- When the device is on, promptly press  again to filter through various vibration modes.
- Promptly press  for lightning speed setting.
- Press and hold each button to turn off their respective motors, making sure that the LED lights are off before storing.

02


CHARGING YOUR NOBÜ:

- When the motor becomes weak or stops, it is time to charge your toy.
- Insert the DC plug into your toys DC charging port (see illustration below).
- Insert the USB end of the charger into any USB dock or socket. The LED light will blink to indicate that the toy is charging.
- After about 2 hours, the LED light will stop blinking and remain on to indicate that the toy is fully charged.

03

CLEANING AND STORAGE:

- Always wash your toy with warm water and soap after use. For best results, we recommend using Nobü antibacterial toy cleaner. Do not use cleaners that contain alcohol, petrol or acetone.
- Rinse your toy with hot water after cleaning and pat dry with a lint-free towel or cloth.
- Store your toy in a clean, dry and dust-free place. Avoid leaving it in direct sunlight, and never expose your toy to extreme heat.



PRODUCT ID: NB001836
UPC: 694182023690

PRODUCT SPECIFICATIONS:

SIZE: 8½" x 1¼" Ø (20.64cm x 3.17cm Ø)
WEIGHT: 328 grams
MATERIALS: Liquid silicone + ABS.
WATERPROOF LEVEL: IPX7 (submersible up to 1 meter for 30 minutes).
NOISE LEVEL: <50dB
INTERNAL BATTERY: Li-ion 902030 mAh
USER TIME: Up to 1 hour depending on power setting.
CHARGING TIME: 2 hours

FOR YOUR SAFETY: Not classified as a medical device. Do not use your toy around your neck, chest or throat area. If you experience severe discomfort during use, stop use immediately and consult your healthcare provider. Sold as an adult novelty only. Not intended to treat, cure, or prevent disease. Keep away from children.

PACKAGING DIMENSIONS: 4½" x 9½" x 3" (width, length, depth).

 nobu_toys
 nobutoyscanada
(514) 855-0045
1 (800) 465-5822
info@nobutoys.com



**VISIT US ONLINE
TO BROWSE
OUR COMPLETE
COLLECTION**

www.nobutoys.com